

*** IMPORTANT INFORMATION ***

BEFORE YOU START

Installation should be performed by a competent person only. This product could be dangerous if incorrectly installed.

Check the pack to ensure all of the components are included.

When you are ready to start, make sure that you have all of the correct tools to hand, have plenty of space, and that the area for building is clean and dry.


Do not rush! Read these instructions first and run through the sequence before you begin. Assembly should be carried out in the steps shown in the following diagrams, constructing one unit at a time and keeping fittings together to avoid loss. Lay large panels on the floor using the packaging for protection. Do not overtighten screws, as this may damage the cabinet.


If any items are missing, or problems arise with fitting, please call the **Manufacturers' Helpline on 01769 575500**.


To clean - use mild soap and water only.


Do not use abrasive cleaners.


HARDWARE:


11 x **A**  15mm


11 x **B**  15mm


9 x **C**  15mm


27 x **D**  15mm

2 x **F**  30mm


6 x **G**  50mm


6 x **H**  15mm


5 x **J**  15mm


 **Please use scissors to open the bag of fittings and then empty the contents into a bowl, so that they do not get lost!**

LEGS:

5 x **W**  15mm


5 x **X**  15mm


2 x **Y***  15mm


2 x **Z***  15mm


*Joined together in the pack

MINIMUM TOOLS REQUIRED:


 **CROSS HEAD SCREWDRIVER**

 **DRILL & DRILL BITS (3mm & 5mm)**

 **HAMMER**


 **SPIRIT LEVEL**

PANELS:



2 x **1** End Panel 1 x **7** Centre Muntin
1 x **2** Base Panel 1 x **8** Drawer Rail
1 x **3** Front Rail
1 x **4** Back Rail
1 x **5** Shelf
1 x **6** Back Panel

IMPORTANT: CAM FITTING AND LOCKING:



Press in **A** firmly. Fully insert **B**. Leave no gaps. Turn **A** clockwise. Turn to 2 o'clock to lock.


STEP 1:

Inset **A** into panels **2**, **3**, **4** and **8** as shown.

Then insert **B** and **C** into panels **2**, **3**, **4** and **8** as shown.

IMPORTANT:

When fitting **A** Arrow points to outside edge.




STEP 2:

Fit panels **2**, **3** and **4** to panel **1**.

Tighten the cams as you go (refer to cam fitting and locking section above).

Then slide panel **6** into the grooves.




STEP 3:

Join panels **7** and **8** together and tighten cam.


Fit the completed panels **7** and **8** to panels **2**, **3** and **4**, using 6 x **G** screws.

Ensure correct orientation of panel **8**, if fitting drawers to this cabinet.



STEP 4:

Fit the other panel **1** to panels **2**, **3**, **4** and **6**, then tighten cams to complete this step.




USING IN A CORNER


In order for this base cabinet to function as a corner cabinet, you must position the end of the cabinet away from the adjacent wall by 227mm for an 800mm Base, 177mm for a 900mm Base & 127mm for a 1000mm Base.

Fit the profiled base corner post (available separately), to the face of the base corner cabinet, as shown. It is important to position the edge of this post approximately 2 to 3mm away from the edge of the door you are fitting to the centre post on the cabinet. Fix using 2 x H, to the rear inside face of the post, using screws D.

To join the adjacent base cabinet to the profiled corner post fitted, line up the end panel with the corner post, as shown, and fix as necessary.



FITTING OF LEGS




Care should be taken when fitting legs and fitting to wall, as unit may be heavy.

JOINING & LEVELLING

LEVELLING: All legs are pre-set at 150mm. Using a spirit level, rotate the bottom of the legs to adjust up and down, to level the unit.


JOINING: Mark 15mm on a 3mm dia. Drill bit with masking tape. Drill between the 2 holes drilled for the hinges, through one cabinet side. Using clamps if necessary, join the cabinets together with 2 x screws F.

FITTING TO WALL: Position the brackets H at the back edge of the cabinet, and mark. Now drill a 3mm pilot hole, and fit the brackets H using screws D. Use appropriate fixings (not supplied), to secure the cabinet to the wall (depending on wall type).




SHELF FITTING

Push shelf support J into chosen shelf position holes, 5 per shelf. Tilt and slide in shelf.



PLINTH FITTING

Lay plinth panel in front of cabinet. Position plinth clip plate Y opposite front cabinet legs. Secure with 2 x screws D. Slide Z into Y. Stand plinth up.



FITTING TO WORKTOP

Use the remaining brackets H and screws D to fit the worktop to the end panels, as required.

NOTES: